




1




2




3



4






1x



1x

1



4




1x





2x

2





3



4






1x



1x

5



6




1x

6






7



8






1x




1x



9




8




1




2







3



10




4





2x

5





1x



1x

6







1x



1x

7




12



1x

8






1x



1x

9




1x



1x

10







1x



1x

11



14





1x





1x

12







1




2





1x

3



16





1x





1x

4





5




6






1x

1




18



2x


2






2x


3





2x


4





5





6







40307







41154



41152





Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :

1-800-422-5346 :

LEGO and the LEGO logo are trademarks of the/son des marques de commerce du/son marcas registradas de LEGO Group. ©2018 The LEGO Group. 6225182