



# Mixels

41531



1



2



3



4



5



6




7



8





9




10



11




12



13



14



15



16







1




2





**3**




17



18





19





**1**



**2**



**3**



4



5



6





4x  
4244369



1x  
6060732



2x  
4531415



2x  
302226



2x  
4568388



4x  
4524644



1x  
6039479



1x  
6060734



1x  
6071222



1x  
6048855



2x  
4273590



6x  
6029946



1x  
6039482



1x  
6046384



3x  
4539097



1x  
393726



2x  
6015891



1x  
6053011



1x  
6043639



1x  
6056842



1x  
4609925



3x  
6099483



2x  
4141580



1x  
613421



**Customer Service**

**Kundenservice**

**Service Consommateurs**

**Servicio Al Consumidor**

**LEGO.com/service or dial**



**00800 5346 5555 :**



**1-800-422-5346 :**



2x  
265326



2x  
407026



3x  
4220515



2x  
4539071



2x  
4504382



1x  
487121





**MELTUS  
41530**



**FLAMZER  
41531**



**BURNARD  
41532**



**INFERNITES  
MAX!**



[LEGO.com/mixels](http://LEGO.com/mixels)





**Mixels**

**CN**  
CARTOON NETWORK



# Mixels



[LEGO.com/mixels](http://LEGO.com/mixels)

