



Friends™

41698



WARNING: CHOKING HAZARD. Toy contains small parts and a small ball. Not for children under 3 years.




AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.



Le jouet contient des petites pièces ainsi qu'une petite boule.
Il ne convient pas aux enfants de moins de 3 ans.




ADVERTENCIA: PELIGRO DE ASFIXIA.


Juguete que contiene partes pequeñas y una pelota pequeña.
No recomendado para niños menores de 3 años.







1






1x



1x

2






1x



1x


3





2x


4






2x


5







2x

6





7







1x




1x


8






9





10







4x



1x

11







12


1



2







13






1x


14






1x

15



1x


16





3x

17




4x

18



19





1x



1x

20






2x


21






22






23






24






2x


25





26







2x

27





28





2x

29








2x

30





31







1x




1x




2x

32

1



2








2x

33





1x

34






2x


35






36






1x

37



2x


38






2x

39




4x

40



41






2x

42





2x

43





2x

44





2x

45





4x

46





2x

47





1x

48





1x




1x




1x

49

1



2








2x




2x

50

1



2









Friends™



2x
6234807



1x
6332010



1x
4111971



4x
6044691



1x
6051511



1x
6117940



2x
4160228



2x
6126046



1x
6313138



4x
6058329



3x
4141607



1x
6373378



1x
302001



1x
4599044



1x
303401



2x
6284577



1x
4525464



1x
6377899



2x
6336971



1x
302324



4x
4121965



2x
6347284



2x
302224



2x
6079007




4x
6378402



1x
6116606



2x
6294227



1x
4609726



1x
4243824



1x
4113993



4x
4529237




3x
4161734




1x
6219794



1x
4114084



2x
6378358



1x
6249092



1x
6221691



2x
6240225



2x
6240215



1x
4529239



2x
6229130



1x
6313099



1x
6310981



3x
6311437



4x
6378330



2x
6275030



1x
6075208



1x
4211157



1x
6326087



2x
6288614



2x
6240211



1x
6209868



1x
6333518



1x
6121816



1x
6308234



1x
4212446



1x
6069006





1x
4537937



1x
4210210



2x
6038459




1x
6370087



2x
6268818



1x
4537936



1x
6212989



4x
6133225



4x
6240550



1x
6172869



2x
6248482



2x
6101073



4x
4611415



2x
6250075



1x
6268952



3x
6186656



1x
6131694



1x
6071608



3x
6193972



11x
6023173



2x
6210729



1x
6138662



1x
6172588



3x
6322818



1x
6176242



1x
6092956



1x
4211006



1x
6373380



1x
6347460



3x
6322821



4x
6206151



2x
6127601



1x
6218929



1x
6330410



4x
6378362



1x
6373377



3x
4569382



2x
6186400



4x
6174192



4x
6314190



1x
6058085



1x
6324713



1x
6378295



3x
6102998




2x
6136419



1x
6097042



2x
6133838



1x
6141594



2x
6333932



5x
6311436



1x
6343806



4x
6378360



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346



Friends™



41699



41718



41697



41698