

BURGER BARN 5602

Color chart. Color chart. Quadro cromático. カラーチャート. 色彩表.

Active step / Étape active / Etapa activa / Azione attiva / Aktiv skede / Active stap / アクティブなステップ / 積極ステップ / Previous step / Étape précédente / Etapa precedente / Azione precedente / Følgende skedet / Vorige step / 前のステップ / 上一歩驟

Age/Años/Âges / Pieces/Piezas/Pieces: 6+ 100

1

8 1x

WARNING: Choking hazard- Small parts. Not for children under 3 years.

ADVERTENCIA: Peligro de asfixia. No recomendado para niños menores de 3 años-contiene piezas pequeñas.

AVVERTISSEMENT: Risque de suffocation. Ne convient pas à un enfant de moins de 3 ans - contient de petits éléments.

WARNING: Risk for kvävning. Ikke egnet til barn under 3 år - inneholder smådeler.

WAARSCHUWING: Stikgevaar. Niet geschikt voor kinderen onder 3 jaar - l.v.m. kleine onderdelen.

注意: 飲み込むと危険です。小さい子供が遊ぶので、3才以下の幼児には与えないでください。

不適合三岁以下儿童。

2

3

1 2 3 4 2x

1 2 3 4 2x

4

5

6

3 4 5 1x 1x 1x



6 7 1x 1x

1 2 3 7 6


3 4 5 3

1 2 2x


7



8




9



10



11



12



13

