



Disney

43241



WARNING: CHOKING HAZARD. Toy contains small parts and a small ball. Not for children under 3 years.



AVERTISSEMENT :

RISQUE D'ÉTOUFFEMENT.



Le jouet contient des petites pièces ainsi qu'une petite boule. Il ne convient pas aux enfants de moins de 3 ans.




ADVERTENCIA:



PELIGRO DE ASFIXIA.

Juguete que contiene partes pequeñas y una pelota pequeña. No recomendado para niños menores de 3 años.







1




2







3





4






5




6








2x

7







8





9






10





2x

11



1x




1x



1x

12







1x





1x


13







14






15




16





3x

17





1x



1x


18






1x

19



4x

20





2x




1x



1x

21




2x



1x


22





1x

23



1x




1x





1x

24






25



26




27






2x


28





4x

29







30





31







32





33






34





2x

35






1x




1x

36



2x

37






2x




1x


38





2x

39







40



41



42





2x

43



2x

44






4x

45





2x




1x

46







47







48





49







50







1x




2x


51






52







4x

53






54





2x


55





2x


56





2x

57







2x



2x


58







4x

59





60







2x





1x

61






62





1x

63







1x



1x

64





2x




1x





1x

65





66







67




68







69







70





71









Disney

4+

43238

43241

Disney FROZEN

Disney PRINCESS



43233

43246

43234



Rebuild
the
world™



